

# 215U-2 wireless mesh networking I/O and gateway installation guide



## HAZLOC NOTICES

The 215U-2 is suitable for use in hazardous locations that are rated Class I Division 2, Groups A, B, C, D.

The 215U-2 must be installed in an enclosure that maintains an ingress protection rating of IP54 and meets the enclosure requirements of EN50014 or EN60079-0.

The RF coaxial cable must be installed in a metallic conduit, per the US National Electrical Code (NEC) or NFPA.

SUP+ and SUP- terminals must only be powered from an NEC Class 2 circuit.

## ⚠ WARNING - EXPLOSION HAZARD

**Do not disconnect equipment while the circuit is live unless the area is known to be free of ignitable concentrations. Substitution of any component may impair suitability for Class I Division 2.**

## NOTE


The 215U-2 module ships from the factory configured for global frequency and power. Set the radio region to access country specific radio options.

## Antenna installation

When selecting an antenna, consider radio proximity. Use Figure 1 as a guide for installing an antenna and attaching it to the 215U-2.

**Note:** Do not operate the radio without an antenna or RF load fitted

**Figure 1. Antenna installation**



## Connecting to the module for configuration

### USB:

- USB Driver “inf” file is available from Eaton Website
- Connect to the device at 192.168.111.1
- The PC will be automatically assigned an IP address via DHCP

### Ethernet:

- Connect to the device at the IP address on the module label
- Assign the PC a static IP address on the 192.168.0/24 subnet

**Username:** user

**Password:** user




Powering Business Worldwide

## SAFETY NOTICE

SELV circuits only. All voltages must be limited to 42.4VAC (peak) or 60VDC.


The following illustrations show the ports on the 215U-2.



### Power supply wiring

The ground (GND) and "SUP -" terminals are connected internally to the ground terminal.


Connect the screw terminal on the end plate to ground for surge protection.



### Expansion I/O power and RS-485 serial connection

An on-board RS-485 terminating resistor provides line termination for long runs.

Enable terminating resistors at far end of the RS-485 cable.



**Eaton**  
1000 Eaton Boulevard  
Cleveland, OH 44122  
United States  
Eaton.com


**Eaton's wireless business**  
www.eaton.com/wireless



### Configuration switches

Use the DIP switches in the side access panel to select analog input voltage and current, and default configuration settings.


DIP	DESCRIPTION
1	AI3 current/voltage
2	AI3 current/voltage
3	AI4 current/voltage
4	AI4 current/voltage
5	Unused
6	Enables default configuration




### Input and output connections

The digital input/output channels can be wired as inputs or outputs.


#### Digital input




#### Digital output




#### Differential 4-20mA inputs (AI1, AI2)




#### Single-ended 4-20mA input (AI3, AI4)



#### Analog output (0 - 20mA)



#### Single-ended voltage input



© 2017 Eaton  
All Rights Reserved  
Printed in USA  
Publication No. IL032051EN  
March 2017

Eaton is a registered trademark.

All other trademarks are property of their respective owners.